



Instructions for attaching UHF timing chips to running shoes
Version: 1.0
Date created: 12-Aug-2010

STEP 1: CHECK THE FORMAT OF THE TIMING CHIP

The UHF timing chip for running is provided on a self adhesive water proof Tyvek strap. This chip will be numbered and programmed ready for use. The adhesive area will be covered with a brown 3M peel off disposable covering (LEFT in photo).





Instructions for attaching UHF timing chips to running shoes
Version: 1.0
Date created: 12-Aug-2010

STEP 2: PEEL OFF THE ADHESIVE AREA COVERING

Carefully peel-off the brown "3M" covering from the adhesive area.





Instructions for attaching UHF timing chips to running shoes
Version: 1.0
Date created: 12-Aug-2010

STEP 3: THREAD THE STRAP THROUGH THE SHOE LACE

Thread the strap through the shoe lace with the label facing outwards.





Instructions for attaching UHF timing chips to running shoes
Version: 1.0
Date created: 12-Aug-2010

STEP 4: FORM A LOOP WITH THE TAG

Form a loop with the tag using the adhesive to bind the two ends of the strap together.





Instructions for attaching UHF timing chips to running shoes
Version: 1.0
Date created: 12-Aug-2010

STEP 5: POSITION THE TAG RACE NUMBER FACING UPWARDS

Rotate the tag so that the Race Number is facing upwards





Instructions for attaching UHF timing chips to running shoes
Version: 1.0
Date created: 12-Aug-2010

STEP 6: CHECK THE FINISHED PRODUCT

The shoe tag should now be attached as a loop through the shoe lace with the Race Number facing upwards.

